



In the Windows Control Panel, select System, Device Manager

Expand the “universal serial bus Controllers” section as per below



Right click on a USB Root Hub and select Properties as per below



Select the "Power Management" tab and uncheck "Allow the computer to turn off the device to save power" and click OK

